


Logitech QuickCam for Notebooks - User Guide




- Features an integrated mount that attaches to any notebook computer
- Shoot 1.3 megapixel photos
- Create and edit high-quality, 640x480 videos
- Get closer with digital zoom, even pan and tilt to get the right shot
- Built-in microphone
- Use the carrying case for easy storage without cable clutter

1. Set Up the Camera

- Insert camera cable into computer's USB port.

2. Launch the Software

- Option 1: Click Start on Windows Taskbar, and then select Programs\Logitech\Logitech Quickcam
- Option 2: Click on the Logitech Quickcam Icon on the desktop
- Click on the QuickCapture link





4. Position the Camera

- Mount camera on notebook screen as shown in picture. The camera can also be held in your hand to snap a picture or to take a video.
- Rotate focus ring to get a sharp image.
- Pivot camera forward or back to place subject in frame.
- View live video to guide your focus adjustments.



- ← Email (do NOT use this feature)
- ← Move to album
- ← Delete photo
- ← Rename file
- ← Use alternate photo editor
- ← Crop
- ← Rotate
- ← Add text
- ← Contrast / Sharpen / Brightness

Tips

- **Lighting.** Shoot pictures and videos with bright light sources behind the camera and out of the picture area.
- **Digital Zoom.** Zoom in or out using your keyboard or mouse while recording videos.


Storing the Camera. Pivot notebook lens cover /mount up to cover lens and pivot the mount arms down; place camera in case as shown in picture.



Using Pictures or Videos

1. Once the pictures / videos are taken, you can view the files as a slideshow. Click on the My Logitech Pictures Icon or go to the Start Menu / Programs / Logitech / My Logitech Pictures.

This view will open:



2. All pictures / videos will be stored in the Pictures and Video's album. **SEE BELOW...**
3. You can elect to "PLAY ALL" slides from an album as a slide show.
4. These picture / video files can be used in various applications like Publisher, PowerPoint, Word, etc. From these programs, choose INSERT PICTURE FROM FILE and locate the image within the files.

MOST IMPORTANT:

When finished taking pictures / recording videos you must move your files to your U drive. To do this:

1. Double click on the MY COMPUTER icon on the desktop.
2. Double click on your U drive.
3. Open the folder MY PICTURES. Resize this folder to fit as a small square on the desktop.
4. Double click on the MY LOGITECH PICTURES icon on the desktop.
5. With the mouse, highlight the photos / videos you created.
6. DRAG the files to the MY PICTURES folder in your U Drive.